





AH5, AH10, AH30 Scale – Rate Installation Procedure: USPS & UPS/FedEx 2009

Step	Action / Comments	
1	<p>Disconnect the scale from both the meter and the power adapter.</p> <p>Note: If the rate card is removed from the scale or installed with the power "ON", severe damage may occur to the scale.</p>	
2	<p>To access the rate card, remove the plastic cover from the right side of the scale.</p> <ul style="list-style-type: none"> - Insert the tip of a flat screwdriver into the horizontal slot at the top of the cover. - Gently pry the cover toward you until the cover drops down. 	
3	<p>Press the black button to release the rate card.</p> <ul style="list-style-type: none"> - The card should move slightly outward. 	
4	<p>Pull the white tab toward you until the card is removed from the scale.</p>	
5	<p>Insert the new rate card with the white label facing up and the EPROM chips (software version 46.6) facing down.</p> <ul style="list-style-type: none"> - Ensure that the correct rate card is being installed. - Rate cards are not interchangeable. - Press on both sides of the rate card while sliding it into the slot. - The rate card is designed to fit in only one direction. - Close the cover. 	
6	<p>The new rates have been successfully loaded.</p> <ul style="list-style-type: none"> - Reconnect the scale to both the meter and the power adapter. - The scale will turn on automatically. - "Checking Memory" and "Checking System" messages will be displayed. 	
7	<p>After the new rate card is installed, please return the old rate card in the prepaid, self addressed padded envelope that arrived with this letter.</p>	

UPS Product Note: The UPS has a number of residential and delivery area service charges. To ensure you properly rate your UPS packages, please check the UPS web site at: <http://www.ups.com/rates>. Select Delivery Area Surcharges on the right for the correct surcharge to be added to the displayed base rate.